Made in the way yon want..



Instructions Manual

Welcomes to the world of

We're committed to helping you create a lifetime of delicious meals for family and friends. To help ensure the longevity and performance of your appliance, keep this guide handy. It will empower you with the best way to use and care for your product. Your satisfaction is our no. 1 goal.



IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- 1. Read all instructions.
- 2. To protect against risk of electrical shock do not put motor body, cord or electrical plug of this Hand Blender in water or other liquid.
- 3. This appliance should not be used by children and care should be taken when used near children.
- 4. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- 5. Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or is dropped or damaged in any manner. Return appliance to the nearest Authorized Service Facility for examination, Repair or electrical or mechanical adjustment.
- 7. The use attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.
- 8. Be Certain chopper adapter is securely locked in place before operating appliance.
- 9. Do not use outdoors.
- 10. Do not let cord hang over edge of table or counter.
- 11. Do not let cord contact hot surfaces, including the stove.
- 12. When mixing liquids, especially hot liquids, use a tall container or make small quantities at a time to reduce spillage.
- 13. Keep hands and utensils out of the container while blending to prevent the possibility of severe injury to persons or damage to the unit. A scraper may be used, but must be used only when the unit is not running.
- 14. Blades are sharp. Handle carefully.
- 15. This product is designed for household use only.

FUNCTIONS





BRACKET HOLDER (Optional)

This Bracket is used to hold the blender it can be attach with any wall.

FITTING OF BLADE

The shaft stub to which the blade attachments are fit sticks out between the side vanes in center of the guard. When fixing a blade, see that the drive pin fits in the recess, in order to help rotate the blade. Fit the blade vertically on the stub or the spring blade may slacken To take off an blade, just pull it off the stub.

IMPORTANT

Do not ever use Handy for more than 1 minute continuously. In such a case, switch off power, Allow the motor to cool down for a few second and then start again.

AFTER EVERY USE OPERATE THE HAND BLENDER IN THE CLEAN WATER

PLEASE READ THIS INSTRUCTION MANUAL CAREFULLY BEFORE USE AND SAVE FOR LATER REFERENCE. UNPACK YOUR HAND BLENDER CAREFULLY (CUTTER BLADES IN BLENDING UNIT ARE SHARP) AND REMOVE PACKING PIECES, LABLES AND STICKERS.

Hassle Free Warranty

We're so confident the quality of our products meets the exacting standards of vallabh®, warranty covers the product to be free of defects in materials and workmanship for a period of ONE YEAR from the date of original retail purchase. During this period, vallabh will, at our option, repair defective parts of the product, providing the Use Care and Safety Advice has been followed. The warranty does not cover damage, defect or failure caused by or resulting from accidents, external damage, alteration, modification, abuse, misuse or misapplication. The warranty does not cover any damage caused by taking the appliance apart yourself, or attempting to repair the appliance yourself.

Please keep your Purchase Receipt and contact us directly at our customer care no. if you encounter any problems with your product.

VALLABH SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT (INCLUDING COLOUR FADING, SCRATCHES OR ACCUMULATED DIRT) WITHOUT FOLLOWING THE USE **NOTE:** Due to the introduction of improvements from time to time, the right is reserved to supply products which differ slightly from those illustrated and described in this publication. Errors and Omissions Excepted.

ALL DISPUTES SHALL BE SUBJECT TO SAMANA JURISDICTION.

Mfd. By: KRISHNA ELECTRICALS. REGD APPLIANCES DIVISION (INDIA) Email :krishnaelectricalappliances@yahoo.com Web: www.krishnaappliances.com Customer care no. 09357962200

TO BE FILLED IN AT SALES POINT

Model:	Motor No:									
Inspected By:	••••									
Date of Sale										
Manufacturing Date:	1	2	3	4	5	6	2013	2015	2017	
8	7	8	9	10	11	12	2014	2016	2018	
Owner's Name & Address:										
Name / Stamp & Address of Dealer:										