## Made in the way you want..

# **Vallabh®**

LIGHT WEIGHT ELECTRIC IRON



Chand



Racer



Magic Line DLX



Slim Line



Aakash



Magic



Jet



Fast Line





Plancha LW-DLX

## Instructions Manual







## KRISHNA

### **ELECTRICALS (REGD.)**

APPLIANCES DIVISION (INDIA)

AN ISO 9001: 2000 COMPANY

Customer Care No. 093579-62200

Email: krishnaelectricalappliances@yahoo.com

\* DESIGN & SFECIfication are subjected to change without prior notice.



#### LIGHT WEIGHT ELECTRIC IRON

#### OPERATION DRY IRONING

- Keep iron on heel rest insert plug pin in wall socket & make mains supply 'ON'.
- Set Temprature regulating knob for desired fabric (./../...) & Indicating light will glow. Wait for indicating light to go off.
- This Indicates that iron is ready for ironing since desired temperature is achieved.
- \* Read this garment lable and follow the manufacturer's ironing\* instruction that are often shown by symbols similar to the following

| Synthetic, Nylon          | MIN   | MIN |
|---------------------------|-------|-----|
| <br>Silk, Polyster, Rayon | •     | - 1 |
| <br>Wool                  | • •   | Ш   |
| <br>Cotton                | • • • | III |
| Linen                     | MAX   | MAX |

#### **Care Maintenance**

- Before cleaning Remove the Plug from wall socket and allow iron to cool down Sufficiently.
- One can wipe it with damp cloth and then dry cloth. Do not use thinner /solvent for cleaning.
- Check regularly whether mains cord is safe to use.

#### **Note**

- Please ensure that while replacing power supply cord an insulation sleeve of fiber glass or equivalent material has to be used over & above cabel insulation.
- If the supply cord is damaged, it must be replaced by manufacturer, its service agent or similarly qualified person in order to avoid hazard.

POWER SUPPLY: 230 v 50 hz AC with Earthing

WATTAGE: 750 watts

TEMPERATURE : Manually adjustable control thermostate







YOU ARE NOW A PROUD OWNER OF THE FINEST IRON.

#### USE & CARE

#### MANUAL

#### **VALLABH**

Iron has been manufactured under stringent quality parameters & make use of latest manufacturing technology.

#### **VALLABH**

Iron has been designed keeping in view ISI standards.

#### **VALLABH**

Iron is most elegant, safe, economical & Backed by efficient after sales services through its dealers & Distributors.

#### **Features**

- Adjustable thermostatic control.
- Flexible & swiveling cord grommet for ease of use & safety.
- Indicating lamp for heater on/off display.
- Aluminium sole plate.
- Thermal fuse for added safety.

#### Do's & Dont's

- Read instructions carefully before operating your iron.
- Connect the iron to plug point only specified on rating lable/ manual.
- The iron should never be left unattended while it is connected to the mains supply.
- Keep iron out of the reach of children.
- Don't allow the cord to touch hot sole plate or any hot surface.
- Take care for arranging cord while in use so that it may not be pulled.
- Always Place the iron with its back (vertical) on firm flat surface during ironing & after use.
- To protect against electric Shock do not immerse iron in water or any liquid, also air may damage the electrical circuit.
- Do not operate the iron with a damaged cord or if the iron has been dropped or damaged. Get it examined/repaired by authorized dealer. Do not try to dissemble it for any reason.
- Don't operate another high wattage appliance on the same circuit.
- Ensure earthing in supply socket for safety.
- Use iron for its intended use & domestic purpose only.
- Avoid use of extensions/extension boards as this may be hazardous.





- 1- Flexible & Swiveling Cord Grommet.
- 2- Indicating Lamp.
- 3- Aluminium Sole plate.
- 4- Thermostatic Control.

# WARRANTY CONDITIONS

If within 12 months from the date of purchase this iron is proved to be defective by reason only of faulty design, workmanship or materials , we undertake at our option to repair the same free of Cost. This warranty does not cover damage.

- (A) Components made out of back of bakelite, rubber part & cord.
- (B) Damage resulting from accidents mishandling or negligence on parts of the customer.
- (C) The card should be filled in and endorsed with the dealer's rubber stamp and signature, without which the warranty will not be valid.

In case of any claim the warranty card should be produced before us or the dealer.

**NOTE:** Due to the introduction of improvements from time to time, the right is reserved to supply products which differ slightly from those illustrated and described in this publication. Errors and Omissions Excepted.

ALL DISPUTES SHALL BE SUBJECT TO SAMANA JURISDICTION.

## **WARRANTY CARD**

(TO BE FILLED IN AT SALES POINT)

| Batch No.                            |  |  |  |  |
|--------------------------------------|--|--|--|--|
| Cash Memo No.                        |  |  |  |  |
| Date of Purchase                     |  |  |  |  |
| Product's Name                       |  |  |  |  |
| Name of Purchaser                    |  |  |  |  |
| Name, Address & Stamp of the dealer: |  |  |  |  |
|                                      |  |  |  |  |
| Signature                            |  |  |  |  |