

Made in the way you want..

Vallabh[®]
HEAVY WEIGHT ELECTRIC IRON

Instruction Manual



Supreme



Super



Plancha DLX-HW

www.krishnaappliances.com

IS: 366

CML 9140566

SAFETY

IS: 302-2-3
CML 9139480



KRISHNA

ELECTRICALS (REGD.)

APPLIANCES DIVISION (INDIA)

AN ISO 9001 : 2000 COMPANY

Customer Care No. 093579-62200

Email: krishnaelectricalappliances@yahoo.com

* DESIGN & SPECIFICATION are subjected to change without prior notice.

Vallabh®

HEAVY WEIGHT ELECTRIC IRON

OPERATION DRY IRONING

- Keep iron on heel rest insert plug pin in wall socket & make mains supply 'ON'.
- Set Temperature regulating knob for desired fabric (./../...) & Indicating light will glow. Wait for indicating light to go off.
- This Indicates that iron is ready for ironing since desired temperature is achieved.

* Read this garment lable and follow the manufacturer's ironing* instruction that are often shown by symbols similar to the following

	Synthetic, Nylon	MIN	MIN
	Silk, Polyster, Rayon	•	I
	Wool	••	II
	Cotton	•••	III
	Linen	MAX	MAX

Care Maintenance

- Before cleaning Remove the Plug from wall socket and allow iron to cool down Sufficiently.
- One can wipe it with damp cloth and then dry cloth. Do not use thinner /solvent for cleaning.
- Check regularly whether mains cord is safe to use.

Note

- Please ensure that while replacing power supply cord an insulation sleeve of fiber glass or equivalent material has to be used over & above cabel insulation.
- If the supply cord is damaged, it must be replaced by manufacturer, its service agent or similarly qualified person in order to avoid hazard.

POWER SUPPLY : 230 v 50 hz AC with Earthing

WATTAGE : 750 watts

TEMPERATURE : Manually adjustable control thermostate

IS: 366



CM/L 9140566

SAFETY



IS: 302-2-3

CM/L 9139480



YOU ARE NOW A PROUD OWNER OF THE FINEST IRON.

VALLABH

Iron has been manufactured under stringent quality parameters & make use of latest manufacturing technology.

VALLABH

Iron has been designed keeping in view ISI standards .

VALLABH

Iron is most elegant, safe, economical & Backed by efficient after sales services through its dealers & Distributors.

Features


- Adjustable thermostatic control.
- Flexible & swiveling cord grommet for ease of use & safety.
- Indicating lamp for heater on/off display.
- Cast Iron sole plate.
- Thermal fuse for added safety.

Do's & Dont's

- Read instructions carefully before operating your iron.
- Connect the iron to plug point only specified on rating table/manual.
- The iron should never be left unattended while it is connected to the mains supply.
- Keep iron out of the reach of children.
- Don't allow the cord to touch hot sole plate or any hot surface.
- Take care for arranging cord while in use so that it may not be pulled.
- Always Place the iron with its back (vertical) on firm flat surface during ironing & after use .
- To protect against electric Shock do not immerse iron in water or any liquid , also air may damage the electrical circuit.
- Do not operate the iron with a damaged cord or if the iron has been dropped or damaged. Get it examined/repared by authorized dealer. Do not try to dissemble it for any reason.
- Don't operate another high wattage appliance on the same circuit.
- Ensure earthing in supply socket for safety.
- Use iron for its intended use & domestic purpose only .
- Avoid use of extensions/extension boards as this may be hazardous.



Know your Dry Iron



- 1- Flexible & Swiveling Cord Grommet.
- 2- Indicating Lamp.
- 3- Cast Iron Sole Plate.
- 4- Thermostatic Control.
- 4- CRCA Cover

WARRANTY CONDITIONS

If within 12 months from the date of purchase this iron is proved to be defective by reason only of faulty design, workmanship or materials, we undertake at our option to repair the same free of Cost. This warranty does not cover damage.

(A) Components made out of back of bakelite, rubber part & cord.

(B) Damage resulting from accidents mishandling or negligence on parts of the customer.

(C) The card should be filled in and endorsed with the dealer's rubber stamp and signature, without which the warranty will not be valid.

In case of any claim the warranty card should be produced before us or the dealer.

NOTE: Due to the introduction of improvements from time to time, the right is reserved to supply products which differ slightly from those illustrated and described in this publication. Errors and Omissions Excepted.

ALL DISPUTES SHALL BE SUBJECT TO SAMANA JURISDICTION.

WARRANTY CARD

Batch No.

Cash Memo No.

Date of Purchase

Product's Name

Name of Purchaser

Name, Address & Stamp of the dealer:

Signature